Boxoft Image To PDF Demo. Purchase from www.Boxoft.com to remove the watermark

PLEASE NOTE

- If R. O. B. is receiving the light signals from the T. V. (as indicated by the L. E. D.) but is still not operating properly, the T. V. brightness may be set too high. Adjust the brightness control on your T. V. to bring the brightness level down.
- If you cannot bring the brightness down far enough using the brightness control, you can attach the enclosed filter to R. O. B.'s eyes.

Peel off the protective paper from the two-sided tape, and attach as shown.



Also peel off the protective film from the filter surface.

- If you use R. O. B. with another T. V., you may have to remove the filter.

ATTENTION

- Si le R.O.B. reçoit les signaux lumineux du téléviseur (tel qu'indiqué au voyant) mais ne fonctionne toujours pas convenablement, il se peut que cela provienne du fait que la luminosité du téléviseur est excessive. Abaissez le niveau de luminosité en vous servant du bouton de contrôle de luminosité de votre téléviseur.
- Si vous ne parvenez pas à abaisser suffisamment le niveau de luminosité en actionnant le bouton de contrôle de luminosité, vous pouvez fixer le filtre ci-attaché aux oeilletons du R.O.B.

Retirez le papier protecteur du ruban à double face et fixez le filtre selon l'illustration.



- Si vous utilisez R.O.B. sur un autre téléviseur, il est possible que vous deviez retirer le filtre.